

# ALIEN

SPECTACULAR

1:2

SCALE

**EASY**  
ASSEMBLY

BUILD THE  
TERRIFYING  
XENOMORPH  
FROM ALIEN

**PACK 12**

KITS 85 - 92

# ALIEN

## PACK 12 | BUILD INSTRUCTIONS



### KIT 85

THE TAIL AND THE DORSAL  
GROWTHS (IV)

### KIT 86

THE TAIL AND THE DORSAL  
GROWTHS (V)

### KIT 87

THE DORSAL GROWTHS (I)

### KIT 88

THE DORSAL GROWTHS (II)

### KIT 89

THE DORSAL GROWTHS (III)

### KIT 90

THE DORSAL GROWTHS (IV)

### KIT 91

THE RIGHT SHOULDER GROWTH

### KIT 92

THE LEFT SHOULDER GROWTH

**WARNING:** Some parts are assembled using magnets. These magnets can cause serious injury if they are swallowed. Keep away from children. If you suspect a magnet has been swallowed, seek medical help straight away.

Some parts may have sharp edges, please handle them with care.

The installation of electronic parts must always be carried out by an adult. When replacing batteries, use the same type of batteries.

Please ensure that the battery compartment is securely fastened before you use the model.

Used batteries should be recycled.

Please make sure to check with your local council how batteries should be disposed of in your area.

Batteries can present a choking danger to small children and may cause serious harm if ingested.

Do not leave them lying around and keep any spare batteries locked away at all times.



**STEPS & TIPS ONLINE**

**Hachette Partworks Ltd**, 4th Floor, Jordan House,  
47 Brunswick Place, London N1 6EB

[www.hachettepartworks.com](http://www.hachettepartworks.com)

© 2024 Hachette Partworks Ltd.

© 2024 20th Century Studios.

ALL RIGHTS RESERVED

All parts belong to a kit. Collectors item for adults.

Not suitable for children under 14.





# KIT 85: THE TAIL AND THE DORSAL GROWTHS (IV)



In this kit you will continue to work on the tail and dorsal appendages.



## PARTS SUPPLIED


Ref	Name	Qty	Ref	Name	Qty
85-1	Tail 15	1	85-5	Back C1	1
85-2	Tail 16	1	85-6	Back C2	1
85-3	Back Protector B6	1	85-7	Connector	2
85-4	Back Protector B7	1	85-8	2.3x6mm screws (1 spare)	5

## KIT 85: THE TAIL AND THE DORSAL GROWTHS (IV)



## KIT 85: THE TAIL AND THE DORSAL GROWTHS (IV)

**85-4 (B7)**




Similarly, test-fit the two pegs on Back Protector B7 **85-4** into the matching holes in back **84-5**. When happy with the fit, glue in place.

3

**85-7**


**85-7**



Take Back C1 **85-5** and Back C2 **85-6** and join them together by fitting two Connectors **85-7** over the raised screw sockets.

4

## KIT 85: THE TAIL AND THE DORSAL GROWTHS (IV)



Secure the Connectors **85-7** in place with four 2.3x6mm screws **85-8**.

5

### KIT 85 IS COMPLETE



*THE TAIL HAS BEEN EXTENDED AND FURTHER WORK COMPLETED ON THE DORSAL GROWTHS.*

# KIT 86: THE TAIL AND THE DORSAL GROWTHS (V)

In this kit you will continue to work on the tail and its dorsal appendages.





## PARTS SUPPLIED

Ref	Name	Qty	Ref	Name	Qty
86-1	Tail 17	1	86-5	Back C5	1
86-2	Tail 18	1	86-6	Connector	2
86-3	Back Protector C3	1	86-7	2.3x6mm screws (1 spare)	7
86-4	Back C4	1			




## KIT 86: TAIL AND DORSAL GROWTHS (V)






## KIT 86: TAIL AND DORSAL GROWTHS (V)

3



Next, Back C5 **86-5** and Back C4 **86-4** are joined together by fitting two Connectors **86-6** over the raised screw sockets.

4



Secure the Connectors **86-6** in place with four 2.3x6mm screws **86-7**.

5



The assembly **85-5/85-6**, from the previous kit, and the assembly **86-4/86-5** are joined together, as shown above. There are raised sockets, shown by the red lines, which fit together.



Turn the assembly over and fix together with two 2.3x6mm screws **86-7**.

**6**

**KIT 86 IS COMPLETE**



*THE TAIL HAS BEEN COMPLETED  
AND FURTHER WORK HAS BEEN  
DONE TO THE DORSAL GROWTHS.*

# KIT 87: THE DORSAL GROWTHS (I)

In this kit you will continue to build the dorsal appendages.

87-1



87-2



87-3



87-4



87-5



87-6



87-7



87-8



## PARTS SUPPLIED


Ref	Name	Qty
87-1	Back D1	1
87-2	Back D2	1
87-3	Back D3	1
87-4	Back D4	1

Ref	Name	Qty
87-5	Back Protector C6	1
87-6	Back Protector C7	1
87-7	Connector	4
87-8	2.3x6mm screws (1 spare)	11


## KIT 87: DORSAL GROWTHS (I)



Take the back assembly **86-4/86-5** which was worked on in the previous kit and test-fit the two pegs on Back Protector C6 **87-5** into the corresponding holes in back **86-4**. When certain of the fit, glue in place. Repeat the process to test-fit the pegs on Back Protector C7 **87-6** into the holes in back **86-5**. When sure of a good fit, glue in place.





Take Back D1 **87-1** and Back D2 **87-2** and join them together by fitting two Connectors **87-7** over the raised screw sockets.



Secure the Connectors **87-7** in place with four 2.3x6mm screws **87-8**.




## KIT 87: DORSAL GROWTHS (I)




## KIT 87: DORSAL GROWTHS (I)

The assembly **87-1/87-2**, from step 3 and the assembly **87-3/87-4** from the previous step are joined together as shown on the left. There are raised sockets, shown by the red lines, which fit together.



6



Turn the combined assembly over and fix the sections together with two 2.3x6mm screws **87-8**, as indicated by the red lines.

7

### KIT 87 IS COMPLETE



*FOLLOWING FURTHER WORK, THE DORSAL GROWTHS ARE ALMOST COMPLETE.*

# KIT 88: THE DORSAL GROWTHS (II)

In this kit you will continue to build the dorsal appendages.

88-1



88-2



88-3



88-4



88-5



## PARTS SUPPLIED

Ref	Name	Qty
88-1	Back Protector D5	1
88-2	Back Protector D6	1
88-3	Back Protector D7	1

Ref	Name	Qty
88-4	Battery Compartment 1	1
88-5	Vertebrae	1

**KIT 88: DORSAL GROWTHS (II)**

1



Diagram 1 shows the back assembly consisting of two parts, 87-3 and 87-4, joined at a curved joint. A ribbed, black, curved piece labeled 88-3 (D7) is positioned above the assembly. Red dashed lines indicate the alignment of two small circular holes on the upper surface of part 87-3 with corresponding holes on the lower surface of part 87-4. The piece 88-3 is shown being inserted into these holes.

Take the back assembly **87-3/87-4** from the previous kit and test-fit the two pegs on Back Protector D7 **88-3** into the corresponding holes in back **87-4**. When sure of a good fit, glue in place. .

2



Diagram 2 shows the back assembly 87-3/87-4. A ribbed, black, curved piece labeled 88-2 (D6) is positioned above the assembly. Red dashed lines indicate the alignment of two small circular holes on the upper surface of part 87-3 with corresponding holes on the lower surface of part 87-4. The piece 88-2 is shown being inserted into these holes.

Similarly, test-fit the two pegs on Back Protector D6 **88-2** into the matching holes in back **87-3**. When happy with the fit, glue in place.

3




Diagram 3 shows the back assembly 87-1, which is a single piece with a curved joint. A ribbed, black, curved piece labeled (D5) 88-1 is positioned above the assembly. Red dashed lines indicate the alignment of two small circular holes on the upper surface of the assembly with corresponding holes on the lower surface. The piece 88-1 is shown being inserted into these holes.

Turn the assembly over and test-fit the pegs on Back Protector D5 **88-1** into the corresponding holes in back **87-1**. When certain of the fit, glue in place.



## KIT 88: DORSAL GROWTHS (II)



Next, take the Vertebrae **88-5** and the Back Battery Compartment **88-4** and place them on the work surface. Study the diagrams carefully and test-fit the eight pegs in the Vertebrae **88-5** into the matching holes in the Battery Compartment **88-4**. When certain of the orientation, glue in place.

## KIT 88 IS COMPLETE



*THE DORSAL GROWTHS HAVE BEEN COMPLETED  
AND THE VERTEBRAE ATTACHED TO THE BACK.*

# KIT 89: THE DORSAL GROWTHS (III)

In this kit you will continue to build the dorsal appendages.

89-1



89-2



89-3



89-4



89-5




## PARTS SUPPLIED

Ref	Name	Qty	Ref	Name	Qty
89-1	Back Battery Compartment	1	89-4	Magnets	8
89-2	Back E1	1	89-5	2.3x6mm screws (1 spare)	7
89-3	Connector	2			

**KIT 89: DORSAL GROWTHS (III)**

1




**89-1**

**88-4**

The Back Battery Compartments **88-4** and **89-1** are joined together, as shown above. Four raised sockets fit into recesses shown by the red lines.

2




**89-5**

**89-1**

**88-4**

Secure the two parts together using four 2.3x6mm screws **89-5**.

3



**89-4**

**89-1**

Glue eight magnets **89-4** into the circular recesses on the Battery Compartment **89-1**, as shown by the red lines. It doesn't matter which way up they are fitted.

## KIT 89: DORSAL GROWTHS (III)



Place the back assembly **88-4/89-1** on the work surface and take the assemblies **82-4/82-5** and **84-4/84-5** which were worked on in pack 11 - kit 83 and kit 85 respectively. Whilst noting the contact areas, test-fit the assemblies onto the Back Battery Compartment **88-4**. When certain of a good, secure fit, glue firmly in place. They will only fit correctly one way round.

4




Repeat the previous step to add the assemblies **86-4/86-5** and **87-3/87-4** to the Back Battery Compartment **88-4**.

5



KIT 89: DORSAL GROWTHS (III)



Two Connectors **89-3** are fitted over the raised screw sockets on Back **89-2**, as shown, and secured in place with two 2.3x6mm screws **89-5**.

6

KIT 89 IS COMPLETE




WORK HAS CONTINUED ON THE BACK BATTERY COMPARTMENT AND THE DORSAL APPENDAGES HAVE BEEN ADDED TO THIS.



# KIT 90: THE DORSAL GROWTHS (IV)


In this kit you will continue to build and add the dorsal appendages.




## PARTS SUPPLIED

Ref	Name	Qty	Ref	Name	Qty
90-1	Back E2	1	90-4	Connector	2
90-2	Back E3	1	90-5	2.3x6mm screws (1 spare)	7
90-3	Back E4	1			

## KIT 90: THE DORSAL GROWTHS (IV)





Take the back assembly **89-2** from the last kit and join it to Back **90-1** using the two previously fitted Connectors **89-3**.



When you are sure the parts are fitted correctly together, secure the connectors **89-3** in place with two 2.3x6mm screws **90-5**.

## KIT 90: THE DORSAL GROWTHS (IV)

In a similar way, join Back E3 **90-2** to Back E4 **90-3** using two Connectors **90-4**.




Fix the Connectors **90-4** in place with four 2.3x6mm screws **90-5**.



## KIT 90: THE DORSAL GROWTHS (IV)

5



Take the back assemblies **89-2/90-1** and **90-2/90-3** and test-fit them together, as shown. There are twelve raised sockets on each that fit together. When sure of their fit, note the contact areas and glue the two assemblies together.



## KIT 90 IS COMPLETE



**A FURTHER DORSAL APPENDAGE  
HAS BEEN CONSTRUCTED.**

# KIT 91: THE RIGHT SHOULDER GROWTH

In this kit you will work on the growth to be attached to the right shoulder.

91-1



91-2



91-3



91-4



91-5



91-6




## PARTS SUPPLIED

Ref	Name	Qty	Ref	Name	Qty
91-1	Shoulder Appendage 1	1	91-4	Shoulder Appendage 4	1
91-2	Shoulder Appendage 2	1	91-5	Connector	4
91-3	Shoulder Appendage 3	1	91-6	2.3x6mm screws (1 spare)	9


**KIT 91: THE RIGHT SHOULDER GROWTH**

1



Take the Shoulder Appendages **91-1** and **91-2** and join them together by fitting two Connectors **91-5** over the raised screw sockets, as shown.

2




Fix the Connectors **91-5** in place with four 2.3x6mm screws **91-6**.

3



Next, take the Shoulder Appendages **91-3** and **91-4** and in a similar way to step 2, join them together by fitting two Connectors **91-5** over the raised screw sockets.

4



Fix the Connectors **91-5** in place with four 2.3x6mm screws **91-6**.

## KIT 91: THE RIGHT SHOULDER GROWTH



Take the assembly **91-1/91-2** from step 2 and test-fit it, as shown, to assembly **91-3/91-4**. When sure of their fit, note the contact areas and glue the two assemblies together.

5

## KIT 91 IS COMPLETE




**THE RIGHT SHOULDER GROWTH  
HAS BEEN CONSTRUCTED.**



# KIT 92: THE LEFT SHOULDER GROWTH

In this kit you will work on the growth to be attached to the left shoulder.




## PARTS SUPPLIED

Ref	Name	Qty	Ref	Name	Qty
92-1	Shoulder Appendage 5	1	92-4	Shoulder Appendage 8	1
92-2	Shoulder Appendage 6	1	92-5	Connector	4
92-3	Shoulder Appendage 7	1	92-6	2.3x6mm screws (1 spare)	9

**KIT 92: THE LEFT SHOULDER GROWTH**

1



**92-5**


**92-5**

**92-1**

**92-2**

Take the Shoulder Appendages **92-1** and **92-2** and join them together by fitting two Connectors **92-5** over the raised screw sockets, as shown.

2



**92-6**

**92-6**



**92-5**

**92-5**

Secure each Connector **92-5** in place using two 2.3x6mm screws **92-6**.

## KIT 92: THE LEFT SHOULDER GROWTH

In a similar way, Shoulder Appendages **92-3** and **92-4** are joined by fitting two Connectors **92-5** over the raised screw sockets.



Fix each Connector **92-5** in place with two 2.3x6mm screws **92-6**.

## KIT 92: THE LEFT SHOULDER GROWTH



The two assemblies **92-1/92-2** and **92-3/92-4** are test-fitted together, as indicated by the red lines. After noting the contact areas, glue the two assemblies firmly together.

5

**KIT 92 AND PACK 12 IS  
NOW COMPLETE**



**THE LEFT SHOULDER GROWTH  
HAS BEEN CONSTRUCTED.**